


How the AQUAbox Straight works



We recommend that the capillary matting slopes away from the AQUAbox at a slight gradient to ensure the effective distribution of water and feed. The ideal depth of the capillary matting below the soil level is between 75mm – 150mm.